

Catalog No. SPST048R

Description: PWR BRKII SHUNT TRIP 48AC/DC

UPC No 783164072471

Home > Circuit Breakers > Accessories

The shunt trip accessory is an electronic module which provides remote control capability to open the circuit breaker. When activated, the shunt trip sends a signal to the trip unit to open the breaker. This allows the trip unit to record, display, and communicate (in MicroVersaTrip PM trip units) that the opening event was initiated by the shunt trip device. The shunt trip is continuously rated and requires no cut-off switch. When energized, the shunt trip supplies +24 Vdc power to the trip unit to power the display. 048R Amps 600 A

Representative Image

Descriptors

Category	Accessories
GO Schedule	A3

Specifications

Frame Type	SK1200
Amperage	600 A
GSA Compliance	No
Stock Status	A

Classifications

UL File #	E11592
CSA File#	LR40350