



Representative Image

Catalog No. SPUV120ACR

Description: PWR BRKII UNDERVOLTAGE RELEASE

UPC No 783164072648

Home > Circuit Breakers > Accessories

The undervoltage release is an electronic module used to open the circuit breaker when the monitored voltage drops below 35-60PERC of its rated value. The undervoltage release "resets" when the monitored voltage is re-established allowing the circuit breaker to reclose (the sealing voltage of the UVR is 60-85PERC of its rated voltage). An undervoltage release trip operation is produced by the MicroVersaTrip^{1/2} Plus unit in response to a signal from the undervoltage release module. This allows the trip unit to record, display, distinguish and communicate (in MicroVersaTrip^{1/2} PM trip units) that the breaker opening event was due to undervoltage release. Operation of the undervoltage release module will prevent breaker contact closure, i.e. "kiss-free" operation. When energized, the undervoltage release supplies +24 Vdc power to the trip unit to power the display. Field installable. 0ACR Frame Rating Amps 2500

Descriptors

Category	Accessories
GO Schedule	A3

Specifications

GSA Compliance	No
Stock Status	A

Classifications

UL File #	E57253
-----------	--------